Enabling SSH in Ubuntu

Update Packages

```
sudo apt update -y
```

Install Open SSH Server

```
sudo apt install openssh-server
```

Make sure it says active (running) in green


```
sudo systemctl status ssh
```

Enable SSH to start automatically on boot

```
sudo systemctl enable ssh
```

Reboot the computer and see if SSH runs on reboot:

```
sudo systemctl status ssh
```



Revision #3
Created 31 March 2024 08:28:57 by Nate Nash
Updated 4 June 2025 23:32:00 by Nate Nash